



Hi-Lux, Inc.

3135 Kashiwa Street, Torrance, CA 90505, Tel: (310) 257-8142, Fax: (310) 257-8096

SHSMT INSTALLTION INSTRUCTION



Front Mount



Rear Mount



You need to install the front mount in front of the dovetail cut and screw the front single screw into the existing screw hole. If your rifle does not have the second screw hole, you need to drill and tap an either 8-32 or 8-40 hole. Some of the sharps may already have the second screw hole drilled and taped an 8-32 hole at manufacturer. Use the two exiting holes on the left receiver to mount the Rear Angle mount. The rear front screw is a 12-24 and the rear back screw is the 10-32. Tighten all the screws on both front and rear mounts before you mount the short scope on. If you have any questions about this product, please feel free to contact us at the toll free no. 1-888-HI-LUX-12 (445-8912) or send us an e-mail to techsupport@hi-luxoptics.com.

WARNING:

You must install the mount securely before you shoot the rifle. This should be done by a competent gunsmith. This mount is designed for the Padersoli's sharps and all other sharps may need a minor modifications on the rear mount and screws.